



DRUID V2 //
SHOCK SET UP - SUPER DELUXE ULTIMATE

ROCKSHOX SUPER DELUXE ULTIMATE SHOCK



STEP 1



Turn the lock-out lever to the fully **OPEN** position (counter-clockwise).

STEP 2



To set the sag, push the shock o-ring all the way to the shock body and carefully sit on the bike wearing your riding kit and measure how far it has moved.

For the Druid V2, we recommend 32-35% sag (or 16-17.5mm of shaft insertion).
*Please reference the chart on page 2 for your recommended [air pressure] starting point in PSI.

As you fine tune the way your Druid feels on the trail, we'd recommend making small and incremental adjustments of 2 PSI.

STEP 3



Turn the Rebound adjuster [red ring] all the way to the closed position (full clockwise). Set the compression adjusters [blue rings] to their middle positions.

The recommended settings are shown on page 2, use this chart to determine your baseline settings.

ROCKSHOX SUPER DELUXE ULTIMATE SHOCK



RIDER WEIGHT		AIR PRESSURE PSI	HIGH SPEED COMPRESSION HSC *	LOW SPEED COMPRESSION LSC *	REBOUND LSR **
120 - 130 lbs	54 - 59 kg	140	-1	-1	13
130 -140 lbs	59 -63 kg	150	-1	-1	13
140 - 150 lbs	63 - 68 kg	160	0	0	12
150 -160 lbs	68 -73 kg	170	0	0	12
160 - 170 lbs	73 - 77 kg	180	0	0	12
170 - 180 lbs	77 - 82 kg	190	0	0	11
180 - 190 lbs	82 - 86 kg	200	0	0	10
190 - 200 lbs	86 - 91 kg	210	0	0	9
200 - 210 lbs	91 - 95 kg	220	0	0	8
210 - 220 lbs	95 - 100 kg	230	0	0	8
220 - 230 lbs	100 - 104 kg	240	0	0	7
230 - 240 lbs	104 - 109 kg	250	0	0	7
240 - 250 lbs	109 - 113 kg	260	0	0	6

*From mid-position

** From closed position

- Tune: DLC OPO

- For more information on the [Super Deluxe Ultimate](#) .

- Compression adjustment is referenced from the mid-position (0). 2 clicks of adjustment are available in either direction, positive or negative from middle. A positive adjustment will provide heavier damping, a negative adjustment will provide lighter damping.