



DRUID V2 //
SHOCK SET UP - SUPER DELUXE ULTIMATE

THE ROCKSHOX SUPER DELUXE ULTIMATE SHOCK



STEP 1



Turn the lock-out lever to the fully **OPEN** position (counter-clockwise).

STEP 2



To set the sag, push the shock o-ring all the way to the shock body and carefully sit on the bike wearing your riding kit and measure how far it has moved.

For the Druid V2, we recommend 32-35% sag (or 16-17.5mm of shaft insertion).
*Please reference the chart on page 2 for your recommended [air pressure] starting point in PSI.

As you fine tune the way your Druid feels on the trail, we'd recommend making small and incremental adjustments of 2 PSI.


STEP 3



Turn the Rebound adjuster [red ring] all the way to the closed position (full clockwise). Set the compression adjusters [blue rings] to their middle positions.

The recommended settings are shown on page 2, use this chart to determine your baseline settings.

THE ROCKSHOX SUPER DELUXE ULTIMATE SHOCK



Rider Weight (lbs)	Shock Air Pressure (PSI)	High Speed Compression (HSC) [from mid-position]	Low Speed Compression (LSC) [from mid-position]	Rebound (LSR) [from mid-position]
120-130	140	-1	-1	13
130-140	150	-1	-1	13
140-150	160	0	0	12
150-160	170	0	0	12
160-170	180	0	0	12
170-180	190	0	0	11
180-190	200	0	0	10
190-200	210	0	0	9
200-210	220	0	0	8
210-220	230	0	0	8
220-230	240	0	0	7
230-240	250	0	0	7
240-250	260	0	0	6

- Tune: DLC OPO

- For more information on the [Super Deluxe Ultimate](#).

- Compression adjustment is referenced from the mid-position (0). 2 clicks of adjustment are available in either direction, positive or negative from middle. A positive adjustment will provide heavier damping, a negative adjustment will provide lighter damping.