



DREADNOUGHT V2 //
SHOCK SET UP - ROCKSHOX VIVID ULTIMATE

SHOCK SET UP



STEP 1



Turn the lock-out lever to the fully OPEN position (counter-clockwise).

STEP 2


To set the sag, push the shock o-ring all the way to the shock body and carefully sit on the bike wearing your riding kit and measure how far it has moved. For the Dreadnought V2, we recommend 28-30% sag (or 16.8-18mm of shaft insertion). Please reference the chart below for your recommended [air pressure] starting point in PSI. As you fine tune the way your Dreadnought feels on the trail, we'd recommend making small and incremental adjustments of 2 PSI.

STEP 3



Turn the Rebound adjuster [red ring] all the way to the closed position (full clockwise). Set the compression adjusters [blue rings] to their middle positions.

SHOCK SET UP



RIDER WEIGHT		AIR PRESSURE	HIGH SPEED COMPRESSION	LOW SPEED COMPRESSION	REBOUND
LBS	KG	PSI	HSC *	LSC *	LSR **
120-130	54-59	160	-1	-1	19
130-140	59-63	170	-1	-1	18
140-150	63-68	180	0	0	16
150-160	68-73	190	0	0	15
160-170	73-77	200	0	0	14
170-180	77-82	210	0	0	14
180-190	82-86	220	0	0	13
190-200	86-91	230	0	0	12
200-210	91-95	240	0	0	12
210-220	95-100	250	0	0	11
220-230	100-104	260	0	0	10
230-240	104-109	270	0	0	9
240-250	109-113	280	0	0	8

*From mid-position

** From closed position

- Tune: R85 C26 - 2 Volume Spacers

- For more information on the [VIVID Ultimate](#).

- Compression adjustment is referenced from the mid-position (0). 2 clicks of adjustment are available in either direction, positive or negative from middle. A positive adjustment will provide heavier damping, a negative adjustment will provide lighter damping.